



Peterson Party Center, Inc.
139 Swanton Street
Winchester, MA 01890
Tel: (781) 729-4000
Fax: (781) 729-4999
www.ppcinc.com

POPCORN INSTRUCTIONS

PREPARE MACHINE: Place the popcorn machine on a flat and level surface. Handle the machine carefully and be aware that the machine has glass sides and plastic doors. Turn all machine switches ON. Let the popcorn kettle heat for about 4 minutes. After the kettle is properly heated, add oil or oil bar to the kettle. Add only 3 kernels to the kettle to test the heat.

START POPPING POPCORN: When the 3 kernels have popped, the kettle is ready for popping. Add the remaining kernels to the kettle. As soon as the kernels start popping rapidly, turn the kettle heat switch OFF so the popcorn in the kettle does not burn. When popping is about 99% complete, dump the kettle into the container. Add oil and kernels as needed. There is no need to wait for 3 kernels to pop after you have made the first batch because the kettle is already heated.

PREPARE POPCORN: Once there is popcorn in the container, add desired ingredients and use a scoop to transfer the popcorn into the necessary holder. Be aware that the popcorn will be hot immediately after popping.

WARNING! Keep kettle switch "OFF" when not popping.

Please be aware that the popcorn machines glass sides and plastic doors are fragile and proper care of the machine is required.