



Peterson Party Center, Inc.  
139 Swanton Street  
Winchester, MA 01890  
Tel: (781) 729-4000  
Fax: (781) 729-4999  
www.ppcinc.com

## OVEN LIGHTING INSTRUCTIONS

**CONNECT PROPANE TANK:** Connect the propane tank to the oven by screwing the regulator into the tank. After properly connecting the propane tank, open the valve to the propane tank. (Keep propane tank as far away from equipment as possible)

**LIGHT OVEN PILOT:** Before lighting pilot, make sure all oven valves are in the OFF position. Open the oven door and take out bottom tray. Under the oven door is a small hole. Use your finger to push up and hold pilot button within the small hole. Hold pilot button for about 1 minute. Light pilot while continuing to hold pilot button for 1 to 2 minutes. After pilot is lit and the button has been held for the recommended time, slowly let out pilot button.

**TURN ON AND HEAT OVEN:** Once the pilot has remained lit after releasing pilot button, replace the oven's bottom tray. To turn on and heat oven, turn oven valve to desired temperature. If oven fails to light, make sure oven temperature is OFF and check oven pilot. Repeat steps as needed.

---

**LIGHTING OVEN BURNERS:** For top burners on single ovens, CONNECT PROPANE TANK and LIGHT OVEN PILOT then turn knob for each individual burner to on position and light with match.

---

***ALWAYS USE CAUTION AND COMMON SENSE WHEN DEALING WITH PROPANE.***

***ALWAYS KEEP OVENS AWAY FROM WIND, RAIN, AND SNOW.***

***WHEN LIGHTING A DOUBLE OVEN ALWAYS LIGHT LOWER CAVITY FIRST.***